



INSTALLATION INSTRUCTIONS Guardian Motorcycle Cover Alarm



WARNING

Please read and understand these instructions completely before installation to avoid possible injury to yourself or damage to the accessory or vehicle.

Step 1



Set alarm upright on surface and ensure switch on side of alarm is in "down" position. Ensure pin is inserted into device.

Step 2



Use Philips head screwdriver to remove back panel and expose battery compartment.

Step 3



Install one 9v battery (not included) and replace back panel.

Step 4



With the switch in the "down" position, test the alarm by pulling the pin. Alarm is very loud -- consider using hearing protection when testing.

Step 5



When you pull the pin, the alarm should sound. Insert the pin back into the device to turn off the alarm.

WARNING



If the switch is moved to the "up" position, the alarm will sound even with the pin inserted. Flip switch to "down" to turn off.