

Trailerable ATV Cover

WARNING

DO NOT apply this cover while the engine is running. **DO NOT** apply this cover to an ATV that is on uneven or unstable ground. If trailering the ATV be sure to load ATV first. Be sure trailer is secure and stable. Engage the parking brake before applying the cover!

APPLYING THE COVER:

ATV should be parked on trailer with no tie-downs or winch strap engaged. There are velcro flaps, front and rear, on the cover that cover pass throughs for tie-downs and winch strap which will be employed once the cover is on the ATV.

- Begin by locating the sew-in FRONT tag at the front of the cover. The front of the cover has three velcro flaps, one lower center for a winch strap and two upper for tie-down locations. The rear of the cover has two upper velcro flaps and the ratchet pocket at the bottom center.
- Orient the cover to the ATV and apply front end first, pulling the bottom edge down to the wheels then pull the back of the cover over the rear of the ATV.
- Straighten cover if necessary and install tie-downs through velcro flaps to rigid, sturdy, parts on the ATV as you normally would for trailering the ATV.
- Pull free end of rope to tighten ratchet. This will take several pulls and you will need to pull the ratchet back into position after each pull.
- Zip ratchet pocket closed.
- Pass female buckle at the end of the web strap under ATV and secure to male buckle closest to the triangular flap and cinch tight.
- Pass male buckle closest to the end of the web strap over the top of the ATV and engage with the female buckle at the triangular flap and cinch tight.



Engage release lever and pull to loosen rope.

