

COVER DIMENSIONS

INSTRUCTIONS FOR USING THIS GUIDE:

Measure your vehicle carefully and use the chart below to help you determine the correct size cover for your scooter. Please take into consideration the accessories you have. You should order the cover *larger* than the dimensions of your scooter.

Your cover should fit so that the cover *is not* touching the ground, preferably about 3"-6" off the ground. This will allow for air to circulate under the cover to help prevent moisture build up.

Please Note: Due to the nature of our overall cover designs, the exact measurements may vary depending on exactly which points you use to measure the cover. These dimensions are a guide, not exact measurements.



SCOOTER COVERS | WEATHERALL PLUS

ALL MEASUREMENTS IN INCHES

ITEM SIZE	LENGTH	FRONT WIDTH	REAR WIDTH	FRONT HEIGHT	REAR HEIGHT
M [PN: 50031-00]	73	29	26	45	26
L (tall windshields) [PN: 05142]	80	34	26	56	38
XL [PN: 50039-00]	90	40	28	48	36

MEDIUM	LARGE	X-LARGE
<p>Best for:</p> <p>Honda Metropolitan, Honda Elite 80, Honda Ruckus, Vespa ET2, Vespa ET4, Vespa Primavera, Vespa Sprint, Vespa LX150, Yamaha C3, Yamaha Yuma, Ather 450x</p>	<p>Best for:</p> <p>Honda Big Ruckus, Honda PCX 150, Vespa Grandtourismo 200, Vespa PX150, Yamaha Riva 125, Yamaha Zuma 125, Kymco Like 150i</p>	<p>Best for:</p> <p>Honda Helix, Honda Reflex, Vespa 946, Yamaha T-Max, Yamaha Majesty 400, Suzuki Bergman 400, Suzuki Bergman 650</p>